

# DTX-PROX

## Firmware Update Guide

**EN**

Thank you for choosing a Yamaha product.

This document explains how to update the firmware of the DTX-PROX and the revision history.

### NOTICE

- Please save your important data onto a USB flash drive before updating the firmware of the DTX-PROX.
- This updater is to be used at the user's own risk.
- DO NOT power off or disconnect the cable from the DTX-PROX during the updating process. Doing so may damage the DTX-PROX.
- DO NOT remove the USB flash drive from the DTX-PROX during the updating process. The DTX-PROX and the USB flash drive may become inoperable.
- If the update failed, and the DTX-PROX no longer operates, run the update program again. If doing so does not solve the problem, please contact your Yamaha dealer.
- This firmware and documentation are the exclusive copyrights of Yamaha Corporation.
- Reproducing or modifying all or parts of this firmware or its documentation without permission is strictly prohibited.
- The company names and product names in this document are the trademarks or registered trademarks of their respective companies.

## Included files

---

The .zip file contains the following files:

- DTX-PROX\_en\_update\_guide\_v\*\*\*.pdf This document (PDF file)
- DTX-PROX\_SETUP.PRG The update program

## Required items

---

- USB flash drive formatted on the DTX-PROX

Please check the URL below for a list of supported USB flash drives.

<https://download.yamaha.com>

After selecting your country and clicking on "Documents and Data" from the "Support" page, enter the model name into the search box.

## Checking the current version

---

Check the version from MENU/Version.

## Updating procedure

---

### NOTICE

Please save your important data onto the USB flash drive before updating the firmware of the DTX-PROX.

1. After downloading, decompress the archived file, and then find the "\*\*\*.PRG" file. Copy the "\*\*\*.PRG" file to the root of the USB flash drive.

2. Make sure to turn the power off, and then connect the USB flash drive to the [USB TO DEVICE] terminal on the rear panel.

3. Hold down the [CLICK] button and press the Standby/On switch to turn the power on.

After a few seconds, the following message will appear.

**Installer**  
**[MENU] : Install**  
**[EXIT] : Delete**  
**Press the button**  
**Yamaha Corp.**

4. Press the [MENU] button.  
The following message will appear.

**Installer**  
**[MENU] : Execute**  
**[EXIT] : Cancel**  
**Program ver.\*.\*\***  
**Yamaha Corp.**

5. Press the [MENU] button again to start the update process.  
The process may take a few minutes.  
When the update process is complete, the following message will appear.

**Installer**  
**Completed.**  
**Turn power off.**  
**Program ver.\*.\*\***  
**Yamaha Corp.**

6. Turn the power off.

**This completes the update process.**

# Troubleshooting

---

- The power was turned off or the USB flash drive was removed before the installation process could be completed.

You need to reinstall the program. Go back to the beginning of the procedure and try installing again.

- An error message appears, and you cannot install the firmware.

Please check that:

- The USB flash drive is inserted correctly.
- There is no dust or dirt on the USB terminal.
- The installation program file is saved at the root of the USB flash drive.
- The data in the USB flash drive or the USB flash drive itself is not corrupted.
- You have the correct file for your drum module.
- The same problem does not occur with a different USB flash drive.

# Main enhancements

---

## **v1.02 → v1.03**

- Fixed minor problems.

## **v1.01 → v1.02**

- Fixed a problem in which the MENU/Utility/Pad/FootClosePos setting was reset to the initial value at power-on.
- Fixed a problem in which audio file playback and the click sound would fall out of sync when the step in which the LIVE SET/SETTING/EDIT/Wav&Click Sync parameter is set to On is being played for the first time after power-on.
- Fixed minor problems.