

Factory reset for Stereo receiver

Attention:

If you execute the factory reset, all setting will get lost and you have to do all settings from the scratch. That also includes the Yamaha Y.P.A.O measurements.

Factory settings can be executed by using the ADVANCED menu by selecting the function INIT-ALL .

If you want to do a reset of your stereo receiver please follow the instructions:

1. Turn off your receiver by hitting the “Power ON/OFF” knob.



2. Push and hold the „RETURN / CONNECT“ key an power on the receiver by pushing the „Power ON / OFF“ key.



3. Please spin the multi Jog „SELECT / Enter“ clock wise until „INIT.....CANCEL“ is shown in the receivers´ display.
After that pus the „Select / Enter“ multi Jog repeatedly until „INIT.....ALL“ is displayed.



4. Now power off the receiver by pushing the „POWER ON / OFF“ key. The receiver is now set to factory settings.

`#factory #reset #initialise #stereo #receiver`