

Nuage I/O Firmware V1.11 Release Notes

Contents

[System Component Compatibility](#)

[Main Revisions and Enhancements](#)

System Component Compatibility

Please make sure to use the appropriate versions of NUAGE system components which are compatible with each other, referring to the following website. Using an unsupported component combination may result in malfunction.

http://www.yamahaproaudio.com/global/en/products/daw_systems/nuage/downloads.jsp

Main Revisions and Enhancements

V1.09 → V1.11

Fixed Bugs

- Solved a problem in which Nuage I/O (Nio) would no longer clock correctly if the word clock source is re-connected to the BNC or AES/EBU on the Nuage I/O, after the unit receives a stable clock. Also solved a problem in which (in the above situation) the sample rate LED on the front panel would not flash even though the unit was not clocking properly.
- Solved a problem in which sync loss may occur among samples between different channels within a Nuage series device or between different Nuage series devices.
- Solved a problem in which the Input Trim/Output Trim functions of the Nuage I/O 16A or 8A8D, which was adjusted by using NUAGE Workgroup Manager, would not be changed correctly.

NOTE

After you update the Nuage I/O firmware by using NUAGE Workgroup Manager, be sure to manually turn on Nuage I/O again.

Company and product names that appear in this document are the trademarks or registered trademarks of their respective companies.

(C) 2013 Yamaha Corporation All Rights Reserved.

Nuage I/O ファームウェア V1.11 リリースノート

目次

[NUAGE システムコンポーネントの互換性](#)

[主なアップデートの内容](#)

NUAGEシステムコンポーネントの互換性

NUAGE システム製品は、下記のウェブサイト参照して互換性のあるバージョンをお使いください。互換性の無いバージョンを組み合わせで使った場合、誤動作の原因になることがあります。

http://www.yamahaproaudio.com/japan/ja/products/daw_systems/nuage/downloads.jsp

主なアップデートの内容

V1.09 → V1.11

修正した不具合

- ワードクロックソースに BNC や AES/EBU を選択し、クロックが正常に動き始めた後にそのクロックを抜き、再接続すると正常にロックしない不具合を修正しました。また、このような場合に、フロントパネルの Sampling Rate LED が点滅しない不具合を併せて修正しました。
- 本体内部のチャンネル間や NUAGE 機器間でサンプルずれが発生することがある不具合を修正しました。
- Workgroup Manager から Nuage I/O 16A または 8A8D の Input Trim/Output Trim を調整して電源をオフにした後、再び電源をオンにした際に設定値が正しく再現されない不具合を修正しました。

NOTE

- NUAGE Workgroup Manager を使って Nuage I/O のファームウェアをアップデートした後には、必ず手動で Nuage I/O の電源を入れ直してください。

本文に掲載されている会社名および商品名等は、各社の登録商標または商標です。

(C) 2013 Yamaha Corporation All Rights Reserved.