

New features via firmware update

The following features are offered on the receiver/amplifier by updating its firmware:

- Compatibility with the Internet Radio stations that use the WMA streaming format
- Bluetooth audio playback function

Using Bluetooth™ components

You can connect a Yamaha Bluetooth Wireless Audio Receiver YBA-10 (sold separately) to the DOCK terminal of this unit and enjoy the music contents stored in your Bluetooth component (such as a portable music player) without wiring between this unit and the Bluetooth component. You need to perform “pairing” the connected Bluetooth receiver and your Bluetooth component in advance.



This unit is compatible with Advanced Audio Distribution Profile (A2DP).

■ Connecting a Bluetooth receiver

Connect a Bluetooth receiver to the DOCK terminal of the rear panel of this unit using its dedicated cable. Also refer to the owner’s manual of your Bluetooth receiver.

■ Pairing the Bluetooth receiver and your Bluetooth component

Pairing must be performed when using a Bluetooth component with the Bluetooth receiver connected to this unit for the first time or if the pairing data has been deleted. “Pairing” refers to the operation of registering a Bluetooth component for Bluetooth communications.



- You need the pairing operation only for the first time when you use the Bluetooth component with the Bluetooth receiver.
- Pairing requires operations on this unit and on the other component with which Bluetooth communications are to be established. If necessary, refer to the other component’s operating instructions.

To ensure security, a time limit of 8 minutes is set for the pairing operation. You are recommended to read and fully understand all the instructions before starting.

1 Rotate the **INPUT selector on the front panel (or set the operation mode selector to **SOURCE** and then press **DOCK** on the remote control) to select “DOCK” as the input source.**

2 Turn on your Bluetooth component and then set the Bluetooth component to the pairing mode.

For details about how to operate the Bluetooth component, refer to the manual of it.

3 Press and hold **PROGRAM on the front panel (or **TITLE** on the remote control) until “Searching...” appears in the front panel display.**



To cancel the pairing, press **PROGRAM** (or **TITLE**) again.

4 Check that the Bluetooth component detects the Bluetooth receiver.

When the Bluetooth component detects the Bluetooth receiver, “YBA-10 YAMAHA” (example) appears in the Bluetooth device list.

5 Select the Bluetooth receiver in the Bluetooth device list and then enter the pass key “0000” on the Bluetooth component.

When the pairing procedure is successful, “Completed” appears in the front panel display.

Note

The Bluetooth receiver can be paired with up to eight Bluetooth components. When pairing is conducted successfully with a ninth component and the pairing data is registered, the pairing data for the least recently used other component is cleared.

■ Playback of the Bluetooth component

1 Rotate the **INPUT selector on the front panel (or set the operation mode selector to **SOURCE** and then press **DOCK** on the remote control) to select “DOCK” as the input source.**

2 Press **PROGRAM on the front panel (or **ENTER** on the remote control).**

The Bluetooth receiver searches and connect to the last connected Bluetooth component.

When the Bluetooth receiver detects the Bluetooth component, “BT connected” appears in the front panel display.

3 Start playback of your Bluetooth component.



To disconnect the Bluetooth receiver from the Bluetooth component, press **PROGRAM** on the front panel (or **RETURN** on the remote control).

■ Status messages

Status message	Descriptions
Searching...	The Bluetooth receiver and the Bluetooth component is in the middle of the pairing. The Bluetooth receiver and the Bluetooth component is in the middle of establishing the connection.
Completed	The pairing is completed.
Canceled	The pairing is canceled.
Not found	The Bluetooth receiver could not find any Bluetooth components.
BT connected	The connection between the Bluetooth receiver and the Bluetooth component is established.
BT Disconnected	The Bluetooth component is disconnected from the Bluetooth receiver.
BT receiver Not Connected	The Bluetooth receiver is not connected to the DOCK terminal. Connect the Bluetooth receiver to the DOCK terminal.
BT receiver Error	This unit detects a problem of the connected Bluetooth receiver. Set this unit to the standby mode and then turn on again.

Bluetooth™

Bluetooth is a registered trademark of the Bluetooth SIG and is used by Yamaha in accordance with a license agreement.